















SAUTER TF

Premium measuring devices for paint coating,

# Features

• II LCD display, backlit, display of all information at a glance

lacquer coating etc.

- Offset-Accur: This function allows you to adjust the instrument precisely on the locally measured range by a two-point calibration. This results in a superior accuracy of approx. 1 % of the measured value
- Scan mode allows continuous measurement or single point measuring mode
- Mini Statistics Kit: displays the measured result, the average value and the max and the min value
- Internal memory up to 99 values
- $\bullet$  Selectable measuring units:  $\mu m,\,mil$
- Base plate and calibration foils included
- Data interface RS-232 standard
- 2 Delivered in a hard carrying case

## SAUTER TG:

• External sensor for difficult-to-access measurements

# Technical data

- Precision:
- Standard: 3 % of measured value or  $\pm$  2,5  $\mu m$
- Offset-Accur: 1 % of measured value or  $\pm$  1  $\mu m$
- Minimal base thickness: 0,3 mm
- Dimensions WxDxH 65x35x126 mm
- · Battery operation, batteries standard 2 x 1.5 V AAA
- Net weight approx. 81 g

# Accessories

**SAUTER TG** 

- Software, interface cable included, SAUTER ATC-01
- Calibration foils for increased measuring accuracy (covers the range from 20 up to 2000  $\mu$ m, with < 3 % tolerance), **SAUTER ATB-US07**
- External sensor, Type FN, for TG, SAUTER ATG 01

























	ISO
E	+4 DAYS

Model	Measuring range	Readout	Test object	Smallest sample surface	Option ISO Calibration Certificate
SAUTER	[Max] µm	[d] µm		(radius) mm	ISO KERN
TF 1250-0.1FN.	100   1250	0,1   1	Combination instrument: F/N	F: Convex: 1,5 Concave: 25	961-112
TG 1250-0.1FN.	100   1250	0,1   1	Combination instrument: F/N	N: Convex: 3 Concave: 50	961-112

# **SAUTER Pictograms:**





## Adjusting program (CAL):

For quick setting of the balance's accuracy. External adjusting weight required.



### Data interface Infrared:

(optocoupler, digital I/O):

To transfer data from the balance to a printer, PC or other peripheral devices.



### **Battery operation:**

Ready for battery operation. The battery type is specified for each device.



# Rechargeable battery pack:

rechargeable set.



## Calibration block:

measuring process.

standard for adjusting or correcting the measuring device.





SWITCH

# Analogue interface:

Control outputs

to connect a suitable peripheral device for analogue processing of the measurements.

to connect relays, signal lamps, valves, etc.



ACCU

# Mains adapter:

230V/50Hz in standard version for EU. On request GB, AUS or USA version available.



PEAK

## Scan mode:

Push and Pull:

continuous capture and display of measurements.



## Statistics:

using the saved values, the device calculates statistical data, such as average value, standard deviation etc.



# Power supply:

Integrated, 230V/50Hz in EU. More standards e.g. GB, AUS or USA on request.

by a single lever movement.



# PC Software:

to transfer the measurements from the device to a PC.



#### Motorised drive:

The mechanical movement is carried out by a motorised drive.



#### Length measurement:

and compression forces.

captures the geometric dimensions of a test object or the movement during a test process.

the measuring device can capture tension




#### Printer:

a printer can be connected to the device to print out the measurements.



# Fast-Move:

the total length of travel can be covered





# GLP/ISO record keeping:

of measurements with date, time and serial number. Only with SAUTER printers.



# ISO Calibration:

The time required for ISO calibration is shown in days in the pictogram.



#### Internal memory:

to save measurements in the device memory.

Data interface RS-232:

bidirectional, for connection



# Measuring units:

Weighing units can be switched to e.g. non-metric at the touch of a key. Please refer to website for more details.



# Measuring with tolerance range:

Upper and lower limiting can be programmed individually, e.g. for sorting and dosing.



1 DAY

# in days in the pictogram.

Package shipment:

Pallet shipment: The time required for internal shipping preparations is shown

The time required for internal

shipping preparations is shown



# ZERO:

Resets the display to "0".



# Warranty:

The warranty period is shown in the pictogram.

in days in the pictogram.



. .....

RS 232

## Data interface USB:

of printer and PC.

To connect the balance to a printer, PC or other peripheral devices.



# Your SAUTER specialist dealer: