

Technical Data Sheet

Pressure • Temperature • Humidity • Air Velocity • Airflow • Sound level

KIRAY 100 Infrared thermometer








Distance from the target

Distance	254	260	508	mm
Diameter	12.7	13	25.4	mm
			D:S=20 13 mm	:1 at 260 mm
<i>MP</i> –				
U() L				



Make sure that the target is larger than the size of the laser sighting.

Infrared thermometer KIRAY 100 with dual laser sighting is a key tool to diagnose, inspect and check any temperature, with the advantage of using "no-contact" technology. You can safely measure surface temperatures of hot objects, dangerous or difficult to access. Perfect tool to take temperature in a house, a garage, a workshop, an office, a car, a kitchen etc...

Technical features

Spectral response	
	D.S : 20:1 (13 mm at 260 mm)
Temperature range	
Accuracy*	
	From +20 to +300°C : ±1% of reading ±1°C
	From +300°C to +800°C : ±1.5%
Infrared repeatability	From -50 to +20°C : ±1.3°C
-	From +20 to +800°C: ±0.5% or ±0.5°C
Display resolution	0.1°C
Response time	
	Adjustable from 0.10 to 1.0 (pre-set at 0.95)
Over range indication	
	Wave length : from 630 nm to 670 nm
3 3	Output < 1mW, Class 2 (II)
Positive or negative	, , , , , , , , , , , , , , , , , , , ,
_	Automatic (no indication for a positive
•	temperature)
	(-) sign for a negative temperature
Display	4 digits with LCD backlighted display
	Automatic after 7 seconds of inactivity
	Flashing signal on display and beep signal
3	with adjustable thresholds
Power supply	
	105 h (inactive laser and backlight)
,	20 h (active laser and backlight)
Use temperature	From 0 to +10°C for a short period
	From +11 to +50 °C for a long period
Storage temperature	
	From 10 to 90%HR in operating mode
	and > 80%RH in storage
Dimensions	
Weight	

^{*}Accuracy for an ambient temperature from 23 to 25°C (with a relative humidity lower than 80% RH)

- 1 Technical unit °C/°F
- 2 Low battery indicator
- 3 Emissivity value = 0.95 (factory setting)
- 4 Max temperature indicator.
- 5 Temperature value
- 6 Current measurement indicator
- 7 HOLD indicator (fixed measurement)
- 8 Laser in operation indicator
- 9 Lock indicator (continuous measurement)
- 10 High alarm symbol (fixed : activated alarm ; flashing + beep : alarm thresholds exceeded)
- 11 Low alarm symbol (fixed : activated alarm ; flashing + beep : alarm thresholds exceeded)

KIRAY 100 buttons



- 1 Up button. It allows to increment emissivity and high/low alarm thresholds. This button also allows in measurement mode to activate or deactivate the laser.
- 2 Down button. It allows to decrement emissivity and high/low alarm thresholds. This button also allows in measurement mode to activate or deactivate the backlight.
- 3 Mode button. It allows to navigate through the modes (emissivity, lock, high alarm, low alarm).

Infrared thermometer, how does it work?

Infrared thermometers can measure the surface temperature of an object. Its optic lens catches the energy emitted and reflected by the object. This energy is collected and focused onto a detector. This information is displayed as temperature. The laser pointer is only used to aim at the target.

Description



Supplied with

- · Case with passer-by belt
- User manual

■ CE Certification



Emitted energy by the

object as radiation

This device meets with following standards' requirements.

EN 50081-1: 1992, Electromagnetic compatibility, Part 1 EN 50082-1: 1992, Electromagnetic compatibility, Part 2

Infrared sensor

Laser sighting

www.kimo.fr

Distributed by:



EXPORT DEPARTMENT

Tel: +33. 1. 60. 06. 69. 25 - Fax: +33. 1. 60. 06. 69. 29

e-mail: export@kimo.fr